

EXHIBITS A1-A6 (Part 12 of 13)

Cisco's Documentation	Arista's Documentation	Supporting Evidence In The Record												
<table border="1"> <thead> <tr> <th>Related Commands</th><th>Command</th><th>Description</th></tr> </thead> <tbody> <tr> <td></td><td><code>lldp reint</code></td><td>Specifies the delay time in seconds for LLDP to initialize on any interface.</td></tr> <tr> <td></td><td><code>lldp holdtime</code></td><td>Specifies the amount of time in seconds that a receiving device should hold the information sent by your device before discarding it.</td></tr> <tr> <td></td><td><code>show lldp timers</code></td><td>Displays the LLDP holdtime, delay time, and update frequency configuration.</td></tr> </tbody> </table> <p>Cisco Nexus 7000 Series NX-OS System Management Command Reference (2013), at 235.</p>	Related Commands	Command	Description		<code>lldp reint</code>	Specifies the delay time in seconds for LLDP to initialize on any interface.		<code>lldp holdtime</code>	Specifies the amount of time in seconds that a receiving device should hold the information sent by your device before discarding it.		<code>show lldp timers</code>	Displays the LLDP holdtime, delay time, and update frequency configuration.	<p>lldp timer</p> <p>The <code>lldp timer</code> command specifies the amount of time a receiving device should hold the information sent by the device before discarding it. The no form of this command removes the configured LLDP timer.</p> <p>Arista User Manual v. 4.14.3F – Rev. 2 (10/2/2014), at 591.</p> <p>See also Arista User Manual v. 4.12.3 (7/17/13), at 464; Arista User Manual, v. 4.11.1 (1/11/13), at 382.</p>	<p>Dkt. 419-10 at PDF p. 391</p>
Related Commands	Command	Description												
	<code>lldp reint</code>	Specifies the delay time in seconds for LLDP to initialize on any interface.												
	<code>lldp holdtime</code>	Specifies the amount of time in seconds that a receiving device should hold the information sent by your device before discarding it.												
	<code>show lldp timers</code>	Displays the LLDP holdtime, delay time, and update frequency configuration.												
<p>lldp tlv-select</p> <p>To configure the type, length, and value (TLV) descriptions to send and receive in Link Layer Discovery Protocol (LLDP) packets, use the <code>lldp tlv-select</code> command. To remove the TLV configuration, use the no form of this command.</p> <pre>lldp tlv-select [dcbxp management-address port-description port-vlan system-capabilities system-description system-name]</pre> <pre>no lldp tlv-select [dcbxp management-address port-description port-vlan system-capabilities system-description system-name]</pre> <p>Cisco Nexus 7000 Series NX-OS System Management Command Reference (2013), at 236.</p>	<p>12.3.3.5 Selecting the LLDP TLV</p> <p>The <code>lldp tlv-select</code> command configures the type, length, and value (TLV) descriptions to send and receive in Link Layer Discovery Protocol (LLDP) packets. Use the no form of this command to remove the TLV configuration.</p> <p>Example</p> <ul style="list-style-type: none"> This command enables the system descriptions to be included in the TLVs. <pre>switch(config)# lldp tlv-select system-description</pre> <p>Arista User Manual v. 4.14.3F – Rev. 2 (10/2/2014), at 578.</p> <p>See also Arista User Manual v. 4.12.3 (7/17/13), at 465; Arista User Manual, v. 4.11.1 (1/11/13), at 368-69.</p>	<p>Dkt. 419-10 at PDF p. 391</p>												

Cisco's Documentation

logging console

To enable logging messages to the console session, use the **logging console** command. To disable logging messages to the console session, use the **no** form of this command.

logging console [*severity-level*]

no logging console

Syntax Description	<p><i>severity-level</i> (Optional) Number of the desired severity level at which messages should be logged. Messages at or numerically lower than the specified level are logged. Severity levels are as follows:</p> <ul style="list-style-type: none"> • 0—emergency: System unusable • 1—alert: Immediate action needed • 2—critical: Critical condition—default level • 3—error: Error condition • 4—warning: Warning condition • 5—notification: Normal but significant condition • 6—informational: Informational message only • 7—debugging: Appears during debugging only
---------------------------	--

Defaults None

Command Modes Global configuration mode

Supported User Roles network-admin
vdc-admin

Command History	Release	Modification
	4.0(1)	This command was introduced.

Usage Guidelines This command does not require a license.

Examples This example shows how to enable logging messages with a severity level of 4 (warning) or higher to the console session:

```
switch# configure terminal
switch(config)# logging console 4
switch(config)#
```

Cisco Nexus 7000 Series NX-OS System Management Command Reference (2013), at 242.

Arista's Documentation

logging trap system

The **logging trap system** command enables the logging of system messages to a remote server, or limits the syslog messages saved to a remote server based on severity. Use this command without a specified level to enable remote logging.

The **no logging trap system** and default **logging trap system** commands clear the specified method list by removing the corresponding logging trap system command from *running-config*.

Platform all
Command Mode Global Configuration

Command Syntax

logging trap system [*FACILITY_LEVEL*] [*CONDITION*] [*PROGRAM*] [*TEXT*]
no logging trap system [*FACILITY_LEVEL*] [*CONDITION*] [*PROGRAM*] [*TEXT*]
default logging trap system [*FACILITY_LEVEL*] [*CONDITION*] [*PROGRAM*] [*TEXT*]

The *TEXT* parameter, when present, is always last. All other parameters can be placed in any order.

Parameters

- **FACILITY_LEVEL** Defines the appropriate facility.
 - <no parameter> Specifies default facility.
 - *facility* <*facility-name*> Specifies named facility.
- **CONDITION** Specifies condition level. Options include:
 - <no parameter> Specifies default condition level.
 - *severity* <*condition-level*> Name of the severity level at which messages should be logged.

Valid *condition-level* options include:

- * 0 or emergencies System is unusable
- * 1 or alerts Immediate action needed
- * 2 or critical Critical conditions
- * 3 or errors Error conditions
- * 4 or warnings Warning conditions
- * 5 or notifications Normal but significant conditions
- * 6 or informational Informational messages
- * 7 or debugging Debugging messages

- **PROGRAM** Filters packets based on program name. Options include:
 - <no parameter> All tags or program names.
 - *tag* *program-name* Specific tag or program name.
- **TEXT** Specifies log message text. Options include:
 - <no parameter> Specify text contained in log message.
 - *contain* *reg-expression* Specify text contained in log message.

Examples

- This command enables the logging of system informational messages to a remote server.

```
switch(config)#logging trap informational
switch(config)#
```

Arista User Manual v. 4.14.3F – Rev. 2 (10/2/2015), at 155.

Supporting Evidence In The Record

Dkt. 419-10 at PDF p. 392

Cisco's Documentation	Arista's Documentation	Supporting Evidence In The Record															
<p>To configure the interval between Precision Time Protocol (PTP) announce messages on an interface or the number of PTP intervals before a timeout occurs on an interface, use the ptp announce command. To remove the interval configuration for PTP messages, use the no form of this command.</p> <p>Cisco Nexus 7000 Series NX-OS System Management Command Reference (2013), at 330.</p>	<p>Set the Peer Delay Request Interval</p> <p>To configure the minimum interval allowed between Precision Time Protocol (PTP) peer delay-request messages, use the ptp pdelay-req interval command.</p> <p>Arista User Manual v. 4.14.3F – Rev. 2 (10/2/2014), at 273.</p> <p><i>See also</i> Arista User Manual v. 4.12.3 (7/17/13), at 216.</p>	Dkt. 419-10 at PDF p. 393															
<p>Examples</p> <p>This example shows how to configure the interval between PTP announce messages on an interface:</p> <pre>switch# configure terminal switch(config)# interface ethernet 5/1 switch(config-if)# ptp announce interval 1 switch(config-if)#</pre> <p>Cisco Nexus 7000 Series NX-OS System Management Command Reference (2013), at 330.</p>	<p>Examples</p> <ul style="list-style-type: none"> This command shows how to configure the interval between PTP announce messages on an interface. <pre>switch(config)# interface ethernet 5 switch(config-if-Et5)# ptp announce interval 1 switch(config-if-Et5)#</pre> <p>Arista User Manual v. 4.14.3F – Rev. 2 (10/2/2014), at 315.</p> <p><i>See also</i> Arista User Manual v. 4.12.3 (7/17/13), at 253; Arista User Manual, v. 4.11.1 (1/11/13), at 199.</p>	Dkt. 419-10 at PDF p. 393															
<table border="1"> <thead> <tr> <th>Related Commands</th><th>Command</th><th>Description</th></tr> </thead> <tbody> <tr> <td></td><td>ptp</td><td>Enables or disables PTP on an interface.</td></tr> <tr> <td></td><td>ptp announce</td><td>Configures the interval between PTP announce messages on an interface or the number of PTP intervals before a timeout occurs on an interface.</td></tr> <tr> <td></td><td>ptp sync interval</td><td>Configures the interval between PTP synchronization messages on an interface.</td></tr> <tr> <td></td><td>ptp vlan vlan</td><td>Configures the PTP VLAN value on an interface.</td></tr> </tbody> </table> <p>Cisco Nexus 7000 Series NX-OS System Management Command Reference (2013), at 333.</p>	Related Commands	Command	Description		ptp	Enables or disables PTP on an interface.		ptp announce	Configures the interval between PTP announce messages on an interface or the number of PTP intervals before a timeout occurs on an interface.		ptp sync interval	Configures the interval between PTP synchronization messages on an interface.		ptp vlan vlan	Configures the PTP VLAN value on an interface.	<p>ptp announce interval</p> <p>The ptp announce interval command configures the interval between PTP announcement messages on or the number of PTP intervals before a timeout occurs. To disable this feature, use the no form of this command.</p> <p>Arista User Manual v. 4.14.3F – Rev. 2 (10/2/2014), at 315.</p> <p><i>See also</i> Arista User Manual v. 4.12.3 (7/17/13), at 253; Arista User Manual, v. 4.11.1 (1/11/13), at 199.</p>	Dkt. 419-10 at PDF p. 393
Related Commands	Command	Description															
	ptp	Enables or disables PTP on an interface.															
	ptp announce	Configures the interval between PTP announce messages on an interface or the number of PTP intervals before a timeout occurs on an interface.															
	ptp sync interval	Configures the interval between PTP synchronization messages on an interface.															
	ptp vlan vlan	Configures the PTP VLAN value on an interface.															

Cisco's Documentation	Arista's Documentation	Supporting Evidence In The Record															
<p>ptp delay-request minimum interval</p> <p>To configure the minimum interval allowed between Precision Time Protocol (PTP) delay-request messages when the port is in the master state, use the ptp delay-request minimum interval command. To remove the minimum interval configuration for PTP delay-request messages, use the no form of this command.</p> <p>Cisco Nexus 7000 Series NX-OS System Management Command Reference (2013), at 332.</p>	<p>ptp delay-req interval</p> <p>The ptp delay-req interval command specifies the time recommended to the slave devices to send delay request messages. You must enable PTP on the switch first and configure the source IP address for PTP communication. To remove the minimum interval configuration for PTP delay-request messages, use the no form of this command.</p> <p>Arista User Manual v. 4.14.3F – Rev. 2 (10/2/2014), at 318.</p> <p>See also Arista User Manual v. 4.12.3 (7/17/13), at 256; Arista User Manual, v. 4.11.1 (1/11/13), at 202.</p>	<p>Dkt. 419-10 at PDF p. 394</p>															
<table border="1"> <thead> <tr> <th>Related Commands</th><th>Command</th><th>Description</th></tr> </thead> <tbody> <tr> <td></td><td>feature ptp</td><td>Enables or disables PTP on the device.</td></tr> <tr> <td></td><td>ptp source</td><td>Configures the source IP address for all PTP packets.</td></tr> <tr> <td></td><td>ptp priority1</td><td>Configures the priority1 value to use when advertising this clock.</td></tr> <tr> <td></td><td>ptp priority2</td><td>Configures the priority2 value to use when advertising this clock.</td></tr> </tbody> </table> <p>Cisco Nexus 7000 Series NX-OS System Management Command Reference (2013), at 334.</p>	Related Commands	Command	Description		feature ptp	Enables or disables PTP on the device.		ptp source	Configures the source IP address for all PTP packets.		ptp priority1	Configures the priority1 value to use when advertising this clock.		ptp priority2	Configures the priority2 value to use when advertising this clock.	<p>ptp source ip</p> <p>The ptp source ip command configures the source IP address for all PTP packets. The IP address can be in IPv4 format. To remove PTP settings, use the no form of this command.</p> <p>Arista User Manual v. 4.14.3F – Rev. 2 (10/2/2014), at 328.</p> <p>See also Arista User Manual v. 4.12.3 (7/17/13), at 264; Arista User Manual, v. 4.11.1 (1/11/13), at 210.</p>	<p>Dkt. 419-10 at PDF p. 394</p>
Related Commands	Command	Description															
	feature ptp	Enables or disables PTP on the device.															
	ptp source	Configures the source IP address for all PTP packets.															
	ptp priority1	Configures the priority1 value to use when advertising this clock.															
	ptp priority2	Configures the priority2 value to use when advertising this clock.															

Cisco's Documentation	Arista's Documentation	Supporting Evidence In The Record																		
<p>ptp priority1</p> <p>To configure the priority1 value when advertising the Precision Time Protocol (PTP) clock, use the ptp priority1 command. To remove the priority1 value, use the no form of this command.</p> <pre>ptp priority1 priority-number no ptp priority1 priority-number</pre> <table><tr><td>Syntax Description</td><td><i>priority-number</i> Priority number. The range is from 0 to 255.</td></tr><tr><td>Defaults</td><td>255</td></tr><tr><td>Command Modes</td><td>Global configuration mode (config)</td></tr><tr><td>Supported User Roles</td><td>network-admin vdc-admin</td></tr><tr><td>Command History</td><td><table><tr><th>Release</th><th>Modification</th></tr><tr><td>5.2(1)</td><td>This command was introduced.</td></tr></table></td></tr><tr><td>Usage Guidelines</td><td>This command does not require a license.</td></tr><tr><td>Examples</td><td><p>This example shows how to configure the priority1 value when advertising the PTP clock:</p><pre>switch# configure terminal switch(config)# ptp priority1 10</pre><p>This example shows how to remove the priority1 value when advertising the PTP clock:</p><pre>switch# configure terminal switch(config)# no ptp priority1 10</pre></td></tr></table> <p>Cisco Nexus 7000 Series NX-OS System Management Command Reference (2013), at 336.</p>	Syntax Description	<i>priority-number</i> Priority number. The range is from 0 to 255.	Defaults	255	Command Modes	Global configuration mode (config)	Supported User Roles	network-admin vdc-admin	Command History	<table><tr><th>Release</th><th>Modification</th></tr><tr><td>5.2(1)</td><td>This command was introduced.</td></tr></table>	Release	Modification	5.2(1)	This command was introduced.	Usage Guidelines	This command does not require a license.	Examples	<p>This example shows how to configure the priority1 value when advertising the PTP clock:</p> <pre>switch# configure terminal switch(config)# ptp priority1 10</pre> <p>This example shows how to remove the priority1 value when advertising the PTP clock:</p> <pre>switch# configure terminal switch(config)# no ptp priority1 10</pre>	<p>Set the PTP Priority1</p> <p>To configure the priority1 value when advertising the clock, use the ptp priority1 command. This value overrides the default criteria for best master clock selection. Lower values take precedence.</p> <ul style="list-style-type: none">The ptp priority1 command configures the priority1 value of 120 to use when advertising the clock. <pre>switch(config)# ptp priority1 120 switch(config)#</pre> <p>Arista User Manual v. 4.14.3F – Rev. 2 (10/2/2014), at 272.</p> <p><i>See also</i> Arista User Manual v. 4.12.3 (7/17/13), at 214-15.</p>	<p>Dkt. 419-10 at PDF p. 395</p>
Syntax Description	<i>priority-number</i> Priority number. The range is from 0 to 255.																			
Defaults	255																			
Command Modes	Global configuration mode (config)																			
Supported User Roles	network-admin vdc-admin																			
Command History	<table><tr><th>Release</th><th>Modification</th></tr><tr><td>5.2(1)</td><td>This command was introduced.</td></tr></table>	Release	Modification	5.2(1)	This command was introduced.															
Release	Modification																			
5.2(1)	This command was introduced.																			
Usage Guidelines	This command does not require a license.																			
Examples	<p>This example shows how to configure the priority1 value when advertising the PTP clock:</p> <pre>switch# configure terminal switch(config)# ptp priority1 10</pre> <p>This example shows how to remove the priority1 value when advertising the PTP clock:</p> <pre>switch# configure terminal switch(config)# no ptp priority1 10</pre>																			

Cisco's Documentation			Arista's Documentation	Supporting Evidence In The Record
Related Commands	Command	Description	<div>ptp domain</div> <p>The ptp domain command configures the domain number to use for the clock. PTP domains allow you to use multiple independent PTP clocking subdomains on a single network. To remove PTP settings, use the no form of this command.</p> <p>Arista User Manual v. 4.14.3F – Rev. 2 (10/2/2014), at 319.</p> <p>See also Arista User Manual v. 4.12.3 (7/17/13), at 257; Arista User Manual, v. 4.11.1 (1/11/13), at 204.</p>	Dkt. 419-10 at PDF p. 396
	feature ptp	Enables or disables PTP on the device.		
	ptp source	Configures the source IP address for all PTP packets.		
	ptp domain	Configures the domain number to use for this clock.		
	ptp priority2	Configures the priority2 value to use when advertising this clock.		
	show ptp brief	Displays the PTP status.		
	show ptp clock	Displays the properties of the local clock.		
	Cisco Nexus 7000 Series NX-OS System Management Command Reference (2013), at 336.			

Cisco's Documentation	Arista's Documentation	Supporting Evidence In The Record
<div><div>ptp priority2</div><div><div>To configure the priority2 value when advertising the Precision Time Protocol (PTP) clock, use the ptp priority2 command. To remove the priority2 value when advertising the PTP, use the no form of this command.</div><div><div>ptp priority2 priority-number</div><div>no ptp priority2 priority-number</div></div></div><div><div>Syntax Description</div><div><div>priority-number</div><div>Priority number. The range is from 0 to 255.</div></div></div><div><div>Defaults</div><div><div>255</div></div></div><div><div>Command Modes</div><div><div>Global configuration mode (config)</div></div></div><div><div>SupportedUserRoles</div><div><div>network-admin</div><div>vdc-admin</div></div></div><div><div>Command History</div><div><div><div>Release</div><div>Modification</div></div><div><div>5.2(1)</div><div>This command was introduced.</div></div></div></div><div><div>Usage Guidelines</div><div><div>This command does not require a license.</div></div></div><div><div>Examples</div><div><div>This example shows how to configure the priority2 value when advertising the PTP clock:</div><div><div>switch# configure terminal</div><div>switch(config)# ptp priority2 1</div></div><div><div>This example shows how to remove the priority2 value configuration for use when advertising the PTP clock:</div><div><div>switch# configure terminal</div><div>switch(config)# no ptp priority2 1</div></div></div></div><div>Cisco Nexus 7000 Series NX-OS System Management Command Reference (2013), at 337.</div></div></div>	<div><div>Set the PTP Priority2</div><div><div>To configure the priority2 value when advertising this clock, use the ptp priority2 command. This value is used to decide between two devices that are otherwise equally matched in the default criteria.</div><div><div>The ptp priority2 command configures the priority2 value of 128 to use when advertising this clock.</div><div><div>switch(config)# ptp priority2 128</div><div>switch(config)#</div></div></div></div><div>Arista User Manual v. 4.14.3F – Rev. 2 (10/2/2014), at 272.</div><div>See also Arista User Manual v. 4.12.3 (7/17/13), at 215.</div></div>	<div>Dkt. 419-10 at PDF p. 397</div>

Cisco's Documentation	Arista's Documentation	Supporting Evidence In The Record															
<table><tr><th>Related Commands</th><th>Command</th><th>Description</th></tr><tr><td></td><td>feature ptp</td><td>Enables or disables PTP on the device.</td></tr><tr><td></td><td>ptp source</td><td>Configures the source IP address for all PTP packets.</td></tr><tr><td></td><td>ptp domain</td><td>Configures the domain number to use for this clock.</td></tr><tr><td></td><td>ptp priority1</td><td>Configures the priority1 value to use when advertising this clock.</td></tr></table> <p>Cisco Nexus 7000 Series NX-OS System Management Command Reference (2013), at 337.</p>	Related Commands	Command	Description		feature ptp	Enables or disables PTP on the device.		ptp source	Configures the source IP address for all PTP packets.		ptp domain	Configures the domain number to use for this clock.		ptp priority1	Configures the priority1 value to use when advertising this clock.	<p>ptp source ip</p> <p>The ptp source ip command configures the source IP address for all PTP packets. The IP address can be in IPv4 format. To remove PTP settings, use the no form of this command.</p> <p>Arista User Manual v. 4.14.3F – Rev. 2 10/2/2014), at 328.</p> <p>See also Arista User Manual v. 4.12.3 (7/17/13), at 264; Arista User Manual, v. 4.11.1 (1/11/13), at 210.</p>	Dkt. 419-10 at PDF p. 398
Related Commands	Command	Description															
	feature ptp	Enables or disables PTP on the device.															
	ptp source	Configures the source IP address for all PTP packets.															
	ptp domain	Configures the domain number to use for this clock.															
	ptp priority1	Configures the priority1 value to use when advertising this clock.															
<table><tr><th>Related Commands</th><th>Command</th><th>Description</th></tr><tr><td></td><td>feature ptp</td><td>Enables or disables PTP on the device.</td></tr><tr><td></td><td>ptp source</td><td>Configures the source IP address for all PTP packets.</td></tr><tr><td></td><td>ptp domain</td><td>Configures the domain number to use for this clock.</td></tr><tr><td></td><td>ptp priority1</td><td>Configures the priority1 value to use when advertising this clock.</td></tr></table> <p>Cisco Nexus 7000 Series NX-OS System Management Command Reference (2013), at 337.</p>	Related Commands	Command	Description		feature ptp	Enables or disables PTP on the device.		ptp source	Configures the source IP address for all PTP packets.		ptp domain	Configures the domain number to use for this clock.		ptp priority1	Configures the priority1 value to use when advertising this clock.	<p>ptp domain</p> <p>The ptp domain command configures the domain number to use for the clock. PTP domains allow you to use multiple independent PTP clocking subdomains on a single network. To remove PTP settings, use the no form of this command.</p> <p>Arista User Manual v. 4.14.3F – Rev. 2 (10/2/2014), at 319.</p> <p>See also Arista User Manual v. 4.12.3 (7/17/13), at 257; Arista User Manual, v. 4.11.1 (1/11/13), at 204.</p>	Dkt. 419-10 at PDF p. 398
Related Commands	Command	Description															
	feature ptp	Enables or disables PTP on the device.															
	ptp source	Configures the source IP address for all PTP packets.															
	ptp domain	Configures the domain number to use for this clock.															
	ptp priority1	Configures the priority1 value to use when advertising this clock.															
<table><tr><th>Command</th><th>Description</th></tr><tr><td>ptp priority1</td><td>Configures the priority1 value to use when advertising this clock.</td></tr><tr><td>ptp priority2</td><td>Configures the priority2 value to use when advertising this clock.</td></tr><tr><td>show ptp brief</td><td>Displays the PTP status.</td></tr><tr><td>show ptp clock</td><td>Displays the properties of the local clock.</td></tr></table> <p>Cisco Nexus 7000 Series NX-OS System Management Command Reference (2013), at 340.</p>	Command	Description	ptp priority1	Configures the priority1 value to use when advertising this clock.	ptp priority2	Configures the priority2 value to use when advertising this clock.	show ptp brief	Displays the PTP status.	show ptp clock	Displays the properties of the local clock.	<p>Set the PTP Priority1</p> <p>To configure the priority1 value when advertising the clock, use the ptp priority1 command. This value overrides the default criteria for best master clock selection. Lower values take precedence.</p> <ul style="list-style-type: none">The ptp priority1 command configures the priority1 value of 120 to use when advertising the clock. <pre>switch(config)# ptp priority1 120 switch(config)#</pre> <p>Set the PTP Priority2</p> <p>To configure the priority2 value when advertising this clock, use the ptp priority2 command. This value is used to decide between two devices that are otherwise equally matched in the default criteria.</p> <ul style="list-style-type: none">The ptp priority2 command configures the priority2 value of 128 to use when advertising this clock. <pre>switch(config)# ptp priority2 128 switch(config)#</pre> <p>Arista User Manual v. 4.14.3F – Rev. 2 (10/2/2014), at 272.</p> <p>See also Arista User Manual v. 4.12.3 (7/17/13), at 214-15.</p>	Dkt. 419-10 at PDF p. 398					
Command	Description																
ptp priority1	Configures the priority1 value to use when advertising this clock.																
ptp priority2	Configures the priority2 value to use when advertising this clock.																
show ptp brief	Displays the PTP status.																
show ptp clock	Displays the properties of the local clock.																

Cisco's Documentation	Arista's Documentation	Supporting Evidence In The Record
<p>ptp sync interval</p> <p>To configure the interval between Precision Time Protocol (PTP) synchronization messages on an interface, use the <code>ptp sync interval</code> command. To remove the interval configuration for PTP messages synchronization, use the <code>no</code> form of this command.</p> <pre>ptp sync interval seconds</pre> <pre>no ptp sync interval seconds</pre> <p>Cisco Nexus 7000 Series NX-OS System Management Command Reference (2013), at 340.</p>	<p>Set the Peer Delay Request Interval</p> <p>To configure the minimum interval allowed between Precision Time Protocol (PTP) peer delay-request messages, use the <code>ptp pdelay-req interval</code> command.</p> <ul style="list-style-type: none"> The <code>ptp pdelay-req interval</code> command configures the minimum interval allowed between Precision Time Protocol (PTP) peer delay-request messages to 3. <pre>switch(config-if-Et5)# ptp pdelay-request interval 3</pre> <pre>switch(config-if-Et5)#</pre> <p>Arista User Manual v. 4.14.3F – Rev. 2 (10/2/2014), at 273.</p> <p>See also Arista User Manual v. 4.12.3 (7/17/13), at 216.</p>	<p>Dkt. 419-10 at PDF p. 399</p>
<p>ptp sync interval</p> <p>To configure the interval between Precision Time Protocol (PTP) synchronization messages on an interface, use the <code>ptp sync interval</code> command. To remove the interval configuration for PTP messages synchronization, use the <code>no</code> form of this command.</p> <pre>ptp sync interval seconds</pre> <pre>no ptp sync interval seconds</pre> <p>Cisco Nexus 7000 Series NX-OS System Management Command Reference (2013), at 340.</p>	<p>ptp delay-req interval</p> <p>The <code>ptp delay-req interval</code> command specifies the time recommended to the slave devices to send delay request messages. You must enable PTP on the switch first and configure the source IP address for PTP communication. To remove the minimum interval configuration for PTP delay-request messages, use the <code>no</code> form of this command.</p> <p>Platform Arad, FM6000</p> <p>Command Mode Interface-Ethernet Configuration</p> <p> Interface-Port Channel Configuration</p> <p>Command Syntax</p> <pre>ptp delay-req interval log_interval</pre> <pre>no ptp delay-req interval</pre> <pre>default ptp delay-req interval</pre> <p>Arista User Manual v. 4.14.3F – Rev. 2 (10/2/2014), at 318.</p> <p>See also Arista User Manual v. 4.12.3 (7/17/13), at 256; Arista User Manual, v. 4.11.1 (1/11/13), at 202.</p>	<p>Dkt. 419-10 at PDF p. 399</p>

Cisco's Documentation			Arista's Documentation	Supporting Evidence In The Record
Related Commands	Command	Description	<p>Examples</p> <ul style="list-style-type: none">This command shows how to configure the minimum interval allowed between PTP delay-request messages.<pre>switch(config)# interface ethernet 5 switch(config-if-Et5) # ptp delay-request interval 3 switch(config-if-Et5) #</pre>This command removes the configured minimum interval allowed between PTP delay-request messages.<pre>switch(config)# interface ethernet 5 switch(config-if-Et5) # no ptp delay-request interval switch(config-if-Et5) #</pre>	Dkt. 419-10 at PDF p. 400
	ptp	Enables or disables PTP on an interface.		
	ptp announce	Configures the interval between PTP announce messages on an interface or the number of PTP intervals before a timeout occurs on an interface.		
	ptp delay-request minimum interval	Configures the minimum interval allowed between PTP delay-request messages when the port is in the master state.		
	ptp vlan vlan	Configures the PTP VLAN value on an interface.		
Cisco Nexus 7000 Series NX-OS System Management Command Reference (2013), at 342.			<p>Arista User Manual v. 4.14.3F – Rev. 2 (10/2/2014), at 318.</p> <p>See also Arista User Manual v. 4.12.3 (7/17/13), at 256; Arista User Manual, v. 4.11.1 (1/11/13), at 202.</p>	
Make sure that you have globally enabled PTP on the device and configured the source IP address for PTP communication.			<p>The ptp delay-req interval command specifies the time recommended to the slave devices to send delay request messages. You must enable PTP on the switch first and configure the source IP address for PTP communication. To remove the minimum interval configuration for PTP delay-request messages, use the no form of this command.</p> <p>Arista User Manual v. 4.14.3F – Rev. 2 (10/2/2014), at 318.</p> <p>See also Arista User Manual v. 4.12.3 (7/17/13), at 256; Arista User Manual, v. 4.11.1 (1/11/13), at 202.</p>	Dkt. 419-10 at PDF p. 400
Cisco Nexus 7000 Series NX-OS System Management Command Reference (2013), at 343.				

Cisco's Documentation			Arista's Documentation	Supporting Evidence In The Record				
Related Commands	Command	Description	<div>ptp announce interval</div> <p>The ptp announce interval command configures the interval between PTP announcement messages on or the number of PTP intervals before a timeout occurs. To disable this feature, use the no form of this command.</p> <table><tr><td>Platform</td><td>Arad, FM6000</td></tr><tr><td>Command Mode</td><td>Interface-Ethernet Configuration Interface-Port Channel Configuration</td></tr></table> <p>Command Syntax</p> <pre>ptp announce interval log_interval no ptp announce interval default ptp announce interval</pre> <p>Parameters</p> <ul style="list-style-type: none">log_interval The number of log seconds between PTP announcement message (base 2 log (seconds)). Value ranges from 0 to 4; default value is 1. <p>Examples</p> <ul style="list-style-type: none">This command shows how to configure the interval between PTP announce messages on an interface.<pre>switch(config)# interface ethernet 5 switch(config-if-Et5)# ptp announce interval 1 switch(config-if-Et5)#</pre>This command removes the configured interval between PTP announce messages on interface Ethernet 5.<pre>switch(config)# interface ethernet 5 switch(config-if-Et5)# no ptp announce interval switch(config-if-Et5)#</pre> <p>Arista User Manual v. 4.14.3F – Rev. 2 (10/2/2014), at 315.</p> <p>See also Arista User Manual v. 4.12.3 (7/17/13), at 253; Arista User Manual, v. 4.11.1 (1/11/13), at 199.</p>	Platform	Arad, FM6000	Command Mode	Interface-Ethernet Configuration Interface-Port Channel Configuration	Dkt. 419-10 at PDF p. 401
Platform	Arad, FM6000							
Command Mode	Interface-Ethernet Configuration Interface-Port Channel Configuration							

Cisco's Documentation

snmp-server user

To configure the Simple Network Management Protocol (SNMP) user information, use the **snmp-server user** command. To disable the configuration or to revert to factory defaults, use the **no** form of this command.

```
snmp-server user username [group-name] [auth {md5 | sha} password [priv {aes-128} password]
[localizedkey] [engineID id]
```

```
no snmp-server user username [group-name] [auth {md5 | sha} password [priv {aes-128}
password] [localizedkey] [engineID id]
```

Syntax Description	username	Name of the user. The name can be any case-sensitive, alphanumeric string up to 32 characters.
	group-name	(Optional) Name of the group. The name can be any case-sensitive, alphanumeric string up to 32 characters.
	auth	(Optional) Sets authentication parameters for the user.
	md5	Uses the MD5 algorithm for authentication.
	sha	Uses the SHA algorithm for authentication.
	password	User password. The password can be any case-sensitive, alphanumeric string up to 64 characters. If you configure the localizedkey keyword, the password can be any case-sensitive, alphanumeric string up to 130 characters.
	priv	(Optional) Sets encryption parameters for the user.
	aes-128	(Optional) Sets the 128-byte AES algorithm for privacy.
	localizedkey	(Optional) Sets passwords in the localized key format. If you configure this keyword, the password can be any case-sensitive, alphanumeric string up to 130 characters.
	engineID id	(Optional) Configures the SNMP Engine ID for a notification target user. The engineID format is a 12-digit colon-separated decimal number.

Cisco Nexus 7000 Series NX-OS System Management Command Reference (2013), at 394.

Arista's Documentation

snmp-server user

The **snmp-server user** command adds a user to a Simple Network Management Protocol (SNMP) group or modifies an existing user's parameters.

To configure a remote user, specify the IP address or port number of the device where the user's remote SNMP agent resides. A remote agent's engine ID must be configured before remote users for that agent are configured. A user's authentication and privacy digests are derived from the engine ID and the user's password. The configuration command fails if the remote engine ID is not configured first.

The **no snmp-server user** and default **snmp-server user** commands remove the user from an SNMP group by deleting the user command from *running-config*.

Platform all
Command Mode Global Configuration

Command Syntax

```
snmp-server user user_name group_name [AGENT] VERSION [ENGINE] [SECURITY]
no snmp-server user user_name group_name [AGENT] VERSION
default snmp-server user user_name group_name [AGENT] VERSION
```

Parameters

- user_name** name of the user on the host that connects to the agent.
- group_name** name of the group to which the user is associated.
- AGENT** location of the host connecting to the SNMP agent. Configuration options include:
 - <no parameter> local SNMP agent.
 - remote addr [udp-port p_num]** remote SNMP agent location (IP address, udp port).
addr denotes the IP address; *p_num* denotes the udp port socket. (default port is 162).
- VERSION** SNMP version; options include:
 - v1** SNMPv1.
 - v2c** SNMPv2c.
 - v3** SNMPv3; enables user-name match authentication.
- ENGINE** **engine ID** used to localize passwords. Available only if **VERSION** is v3.
 - <no parameter> Passwords localized by SNMP copy specified by *agent*.
 - localized engineID** octet string of engineID.
- SECURITY** Specifies authentication and encryption levels. Available only if **VERSION** is v3. Encryption is available only when authentication is configured.
 - <no parameter> no authentication or encryption.
 - auth a_meth a_pass [priv e_meth e_pass]** authentication and encryption parameters.
a-meth authentication method: options are md5 (HMAC-MD5-96) and sha (HMAC-SHA-96).
a-pass authentication string for users receiving packets.
e-meth encryption method: tions are aes (AES-128) and des (CBC-DES).
e-pass encryption string for the users sending packets.

Arista User Manual v. 4.14.3F – Rev. 2 (10/2/2014), at 1999.

Supporting Evidence In The Record

Dkt. 419-10 at PDF pp. 402-403

Cisco's Documentation	Arista's Documentation	Supporting Evidence In The Record
	<p><i>See also</i> Arista User Manual v. 4.12.3 (7/17/13), at 1689; Arista User Manual, v. 4.11.1 (1/11/13), at 1374; Arista User Manual v. 4.10.3 (10/22/12), at 1141; Arista User Manual v. 4.9.3.2 (5/3/12), at 896; Arista User Manual v. 4.8.2 (11/18/11), at 703; Arista User Manual v. 4.7.3 (7/18/11), at 559.</p>	
<p>Examples</p> <p>This example shows how to display the EEE status on an interface:</p> <pre>switch# show interface ethernet2/6 Ethernet2/6 is down (Link not connected) admin state is up, Dedicated Interface Hardware: 10000 Ethernet, address: 0022.5579.de41 (bia 001b.54c1.af5d) MTU 1500 bytes, BW 10000000 Kbit, DLY 10 usec reliability 255/255, txload 1/255, rxload 1/255 Encapsulation ARPA, medium is broadcast auto-duplex, auto-speed, media type is 10G Beacon is turned off Auto-Negotiation is turned off Input flow-control is off, output flow-control is off Auto-mdix is turned off Rate mode is shared Switchport monitor is off EtherType is 0x8100 EEE (efficient-ethernet) : n/a Last link flapped never Last clearing of "show interface" counters never 0 interface resets 30 seconds input rate 0 bits/sec, 0 packets/sec 30 seconds output rate 0 bits/sec, 0 packets/sec Load-Interval #2: 5 minute (300 seconds)</pre> <p>Cisco Nexus 7000 Series NX-OS System Management Command Reference (2013), at 514.</p>	<p>Example</p> <ul style="list-style-type: none"> This command assigns the MAC address of 001c.2804.17e1 to Ethernet interface 7, then displays interface parameters, including the assigned address. <pre>switch(config)#interface ethernet 7 switch(config-if-Et7)#mac-address 001c.2804.17e1 switch(config-if-Et7)#show interface ethernet 7 Ethernet3 is up, line protocol is up (connected) Hardware is Ethernet, address is 001c.2804.17e1 (bia 001c.7312.02e2) Description: b.e45 MTU 9212 bytes, BW 10000000 Kbit Full-duplex, 10Gb/s, auto negotiation: off Last clearing of "show interface" counters never 5 seconds input rate 7.84 kbps (0.0% with framing), 10 packets/sec 5 seconds output rate 270 kbps (0.0% with framing), 24 packets/sec 1363799 packets input, 222736140 bytes Received 0 broadcasts, 290904 multicast 0 runs, 0 giants 0 input errors, 0 CRC, 0 alignment, 0 symbol 0 PAUSE input 2264927 packets output, 2348747214 bytes Sent 0 broadcasts, 28573 multicast 0 output errors, 0 collisions 0 late collision, 0 deferred 0 PAUSE output switch(config-if-Et7)#</pre> <p>Arista User Manual v. 4.14.3F – Rev. 2 (10/2/2014), at 437.</p> <p><i>See also</i> Arista User Manual v. 4.12.3 (7/17/13), at 371; Arista User Manual, v. 4.11.1 (1/11/13), at 312; Arista User Manual v. 4.10.3 (10/22/12), at 270; Arista User Manual v. 4.9.3.2 (5/3/12), at 252.</p>	<p>Dkt. 419-10 at PDF p. 403</p>

Cisco's Documentation			Arista's Documentation	Supporting Evidence In The Record
Related Commands	Command	Description	lldp tlv-select The lldp tlv-select command allows the user to specify the TLVs to send and receive in LLDP packets. The available TLVs are management-address, port-description, port-vlan, system-capabilities, system-description, and system-name. Arista User Manual v. 4.14.3F – Rev. 2 (10/2/2014), at 592. <i>See also</i> Arista User Manual v. 4.12.3 (7/17/13), at 465; Arista User Manual, v. 4.11.1 (1/11/13), at 383.	Dkt. 419-10 at PDF p. 404
Cisco Nexus 7000 Series NX-OS System Management Command Reference (2013), at 515.				
Related Commands	Command	Description	lldp transmit The lldp transmit command enables the transmission of LLDP packets on an interface. After you globally enable LLDP, it is enabled on all supported interfaces by default. Arista User Manual v. 4.14.3F – Rev. 2 (10/2/2014), at 593. <i>See also</i> Arista User Manual v. 4.12.3 (7/17/13), at 466; Arista User Manual, v. 4.11.1 (1/11/13), at 384.	Dkt. 419-10 at PDF p. 404
Cisco Nexus 7000 Series NX-OS System Management Command Reference (2013), at 522.				
Related Commands	Command	Description	12.3.3.2 Setting the LLDP Hold Time The lldp holdtime command specifies the amount of time in seconds that a receiving device should hold the information sent by your device before discarding it. Arista User Manual v. 4.14.3F – Rev. 2 (10/2/2014), at 578. <i>See also</i> Arista User Manual v. 4.12.3 (7/17/13), at 450; Arista User Manual, v. 4.11.1 (1/11/13), at 368	Dkt. 419-10 at PDF p. 404
Cisco Nexus 7000 Series NX-OS System Management Command Reference (2013), at 522.				

Cisco's Documentation			Arista's Documentation	Supporting Evidence In The Record
Related Commands	Command	Description	<p>lldp reinit</p> <p>The lldp reinit command specifies the delay time in seconds for LLDP to initialize on any interface.</p> <p>Arista User Manual v. 4.14.3F – Rev. 2 (10/2/2014), at 589.</p> <p>See also Arista User Manual v. 4.12.3 (7/17/13), at 462; Arista User Manual, v. 4.11.1 (1/11/13), at 380.</p>	Dkt. 419-10 at PDF p. 405
	show lldp holdtime	Specifies the amount of time in seconds that a receiving device should hold the information sent by your device before discarding it.		
	lldp reinit	Specifies the delay time in seconds for LLDP to initialize on any interface		
	lldp timer	Specifies the transmission frequency of LLDP updates in seconds.		
Cisco Nexus 7000 Series NX-OS System Management Command Reference (2013), at 522.				
Related Commands	Command	Description	<p>show lldp traffic</p> <p>The show lldp traffic command displays LLDP counters, including the number of packets sent and received, and the number of packets discarded.</p> <p>Platform all Command Mode EXEC</p> <p>Command Syntax</p> <p>show lldp traffic [INTERFACE]</p> <p>Parameters</p> <ul style="list-style-type: none"> • INTERFACE Interface type and numbers. Options include: <ul style="list-style-type: none"> — <no parameter> Display information for all interfaces. — ethernet e_range Ethernet interface range specified by e_range. — management m_range Management interface range specified by m_range. <p>Valid e_range and m_range formats include number, number range, or comma-delimited list of numbers and ranges.</p> <p>Arista User Manual v. 4.14.3F – Rev. 2 (10/2/2014), at 599.</p> <p>See also Arista User Manual v. 4.12.3 (7/17/13), at 472; Arista User Manual, v. 4.11.1 (1/11/13), at 390.</p>	Dkt. 419-10 at PDF p. 405
	show lldp traffic interface ethernet	Displays the number of LLDP packets sent and received on the interface.		
	show running-config lldp	Displays the global LLDP configuration.		
Cisco Nexus 7000 Series NX-OS System Management Command Reference (2013), at 527.				

Cisco's Documentation			Arista's Documentation	Supporting Evidence In The Record
Related Commands	Command	Description	<p>show lldp traffic</p> <p>The show lldp traffic command displays LLDP counters, including the number of packets sent and received, and the number of packets discarded.</p> <p>Platform all Command Mode EXEC</p> <p>Command Syntax</p> <p>show lldp traffic [<i>INTERFACE</i>]</p> <p>Parameters</p> <ul style="list-style-type: none"> • <i>INTERFACE</i> Interface type and numbers. Options include: <ul style="list-style-type: none"> — <no parameter> Display information for all interfaces. — ethernet <i>e_range</i> Ethernet interface range specified by <i>e_range</i>. — management <i>m_range</i> Management interface range specified by <i>m_range</i>. <p>Valid <i>e_range</i> and <i>m_range</i> formats include number, number range, or comma-delimited list of numbers and ranges.</p> <p>Arista User Manual v. 4.14.3F – Rev. 2 (10/2/2014), at 599.</p> <p>See also Arista User Manual v. 4.12.3 (7/17/13), at 472; Arista User Manual, v. 4.11.1 (1/11/13), at 390.</p>	Dkt. 419-10 at PDF p. 406
<p>Cisco Nexus 7000 Series NX-OS System Management Command Reference (2013), at 529.</p>				

Cisco's Documentation

show ptp clock

To display the Precision Time Protocol (PTP) clock information, use the `show ptp clock` command.

`show ptp clock`

Syntax Description This command has no arguments or keywords.

Defaults None

Command Modes Any command mode

Supported User Roles network-admin
network-operator
vdc-admin
vdc-operator

Command History	Release	Modification
	5.2(1)	This command was introduced.

Usage Guidelines This command does not require a license.

Examples This example shows how to display the PTP clock information:

```
switch# show ptp clock
PTP Device Type: Boundary clock
Clock Identity: 0:18:ba:ff:ff:d8: e:17
Clock Domain: 0
Number of PTP ports: 2
Priority1: 255
Priority2: 255
Clock Quality:
  Class: 248
  Accuracy: 254
  Offset (log variance): 65535
Offset From Master: 0
Mean Path Delay: 0
Steps removed: 1
Local clock time: Sun Jan 15 20:57:29 2011
```

Cisco Nexus 7000 Series NX-OS System Management Command Reference (2013), at 601.

Arista's Documentation

Show PTP Clock and Offset

To display the Precision Time Protocol (PTP) local clock and offset, use the `show ptp clock` command.

- The `show ptp clock` command displays the Precision Time Protocol (PTP) local clock and offset.

```
switch# show ptp clock
PTP Mode: Boundary Clock
Clock Identity: 0x00:1c:73:ff:ff:1e:83:24
Clock Domain: 1
Number of PTP ports: 24
Priority1: 128
Priority2: 128
Clock Quality:
  Class: 248
  Accuracy: 0x30
  Offset Scaled Log Variance: 0xffff
Offset From Master: 0
Mean Path Delay: 0
Steps Removed: 0
switch#
```

Arista User Manual v. 4.14.3F – Rev. 2 (10/2/2014), at 275.

See also Arista User Manual v. 4.12.3 (7/17/13), at 217.

Supporting Evidence In The Record

Dkt. 419-10 at PDF p. 407

Cisco's Documentation

show ptp clock foreign-masters-record

To display information about the state of foreign masters known to the Precision Time Protocol (PTP) process, use the `show ptp clocks foreign-masters-record` command.

`show ptp clock foreign-masters-record {interface [ethernet]}`

Syntax Description	interface	Specifies an interface.
	ethernet	(Optional) Specifies an Ethernet interface.

Defaults None

Command Modes Any command mode

Supported User Roles network-admin
network-operator
vdc-admin
vdc-operator

Command History	Release	Modification
	5.2(1)	This command was introduced.

Usage Guidelines This command does not require a license.

Examples This example shows how to display information about the state of foreign masters known to the PTP process:

```
switch# show ptp clock foreign-masters-record interface ethernet 7/1
RP/0/0/CPU0:demo#show ptp clocks foreign-masters
P1=Priority1, P2=Priority2, C=Class, A=Accuracy,
OSLV=Offset-Scaled-Log-Variance, SR=Steps-Removed
GM=Is grandmaster
```

Interface	Clock-ID	P1	P2	C	A	OSLV	SR	
Eth7/10	0:18:ba:ff:ff:d8: e:16	255	255	248	254	65535	0	GM
Eth7/1	0:18:ba:ff:ff:d8: e:16	255	255	248	254	65535	0	GM

Cisco Nexus 7000 Series NX-OS System Management Command Reference (2013), at 603.

Arista's Documentation

Show PTP Foreign Master

To display information about the state of foreign masters known to the Precision Time Protocol (PTP) process, use the `show ptp foreign-master-record` command.

- The `show ptp foreign-master-records` command displays information about the state of foreign masters known to the PTP process.

```
switch# show ptp clocks foreign-masters-record
No Foreign Master Records
switch#
```

Arista User Manual v. 4.14.3F – Rev. 2 (10/2/2014), at 277.

See also Arista User Manual v. 4.12.3 (7/17/13), at 219-220.

Supporting Evidence In The Record

Dkt. 419-10 at PDF p. 408

Cisco's Documentation	Arista's Documentation	Supporting Evidence In The Record																								
<div>Examples</div> <div>This example shows how to display information about the state of foreign masters known to the PTP process:</div> <div>switch# show ptp clock foreign-masters-record interface ethernet 7/1 RP/0/0/CPU0:demo#show ptp clocks foreign-masters P1=Priority1, P2=Priority2, C=Class, A=Accuracy, OSLV=Offset-Scaled-Log-Variance, SR=Steps-Removed GM=Is grandmaster</div> <div><table><tr><th>Interface</th><th>Clock-ID</th><th>P1</th><th>P2</th><th>C</th><th>A</th><th>OSLV</th><th>SR</th></tr><tr><td>Eth7/10</td><td>0:18:ba:ff:ff:d8: e:16</td><td>255</td><td>255</td><td>248</td><td>254</td><td>65535</td><td>0 GM</td></tr><tr><td>Eth7/1</td><td>0:18:ba:ff:ff:d8: e:16</td><td>255</td><td>255</td><td>248</td><td>254</td><td>65535</td><td>0 GM</td></tr></table></div> <div>Cisco Nexus 7000 Series NX-OS System Management Command Reference (2013), at 603.</div>	Interface	Clock-ID	P1	P2	C	A	OSLV	SR	Eth7/10	0:18:ba:ff:ff:d8: e:16	255	255	248	254	65535	0 GM	Eth7/1	0:18:ba:ff:ff:d8: e:16	255	255	248	254	65535	0 GM	<div>Examples</div> <div><ul style="list-style-type: none">This command shows how to display information about the state of foreign masters known to the PTP process.</div> <div>switch# show ptp clocks foreign-masters-record No Foreign Master Records switch#</div> <div>Arista User Manual v. 4.14.3F – Rev. 2 (10/2/2014), at 349.</div> <div>See also Arista User Manual v. 4.12.3 (7/17/13), at 282; Arista User Manual, v. 4.11.1 (1/11/13), at 228.</div>	<div>Dkt. 419-10 at PDF p. 409</div>
Interface	Clock-ID	P1	P2	C	A	OSLV	SR																			
Eth7/10	0:18:ba:ff:ff:d8: e:16	255	255	248	254	65535	0 GM																			
Eth7/1	0:18:ba:ff:ff:d8: e:16	255	255	248	254	65535	0 GM																			

Cisco's Documentation

show ptp parent

To display information about the parent and grand master of the Precision Time Protocol (PTP) clock, use the **show ptp parent** command.

```
show ptp parent
```

Syntax Description This command has no arguments or keywords.

Defaults None

Command Modes Any command mode

Supported User Roles

- network-admin
- network-operator
- vdc-admin
- vdc-operator

Release	Modification
5.2(1)	This command was introduced.

Usage Guidelines This command does not require a license.

Examples This example shows how to display information about the parent and grand master of the PTP clock:

```
switch# show ptp parent
Parent Clock:
Parent Clock Identity: 0:18:ba:ff:ff:d8: e:16
Parent Port Number: 1546
Observed Parent Offset (log variance): N/A
Observed Parent Clock Phase Change Rate: N/A

Grandmaster Clock:
Grandmaster Clock Identity: 0:18:ba:ff:ff:d8: e:16
Grandmaster Clock Quality:
Class: 248
Accuracy: 254
Offset (log variance): 65535
Priority1: 255
Priority2: 255
```

Cisco Nexus 7000 Series NX-OS System Management Command Reference (2013), at 607.

Arista's Documentation

Show PTP Parent Information

To display information about the parent and grand master of the Precision Time Protocol (PTP) clock, use the **show ptp parent** command.

- The **show ptp parent** command displays information about the parent and grand master of the Precision Time Protocol (PTP) clock.

```
switch# show ptp parent
Parent Clock:
Parent Clock Identity: 0x00:1c:73:ff:ff:00:72:40
Parent Port Number: 0
Parent IP Address: N/A
Observed Parent Offset (log variance): N/A
Observed Parent Clock Phase Change Rate: N/A

Grandmaster Clock:
Grandmaster Clock Identity: 0x00:1c:73:ff:ff:00:72:40
Grandmaster Clock Quality:
Class: 248
Accuracy: 0x30
Offset Scaled Log Variance: 0xffff
Priority1: 128
Priority2: 128
switch#
```

Arista User Manual v. 4.14.3F – Rev. 2 (10/2/2014), at 275.

See also Arista User Manual v. 4.12.3 (7/17/13), at 217.

Supporting Evidence In The Record

Dkt. 419-10 at PDF p. 410

Cisco’s Documentation	Arista’s Documentation	Supporting Evidence In The Record				
<div><div>show ptp parent</div><div>To display information about the parent and grand master of the Precision Time Protocol (PTP) clock, use the show ptp parent command.</div><div>show ptp parent</div><div><div>Syntax Description</div><div>This command has no arguments or keywords.</div></div><div><div>Defaults</div><div>None</div></div><div><div>Command Modes</div><div>Any command mode</div></div><div><div>SupportedUserRoles</div><div>network-admin network-operator vdc-admin vdc-operator</div></div><div><div>Command History</div><div><table><tr><th>Release</th><th>Modification</th></tr><tr><td>5.2(1)</td><td>This command was introduced.</td></tr></table></div></div><div><div>Usage Guidelines</div><div>This command does not require a license.</div></div><div><div>Examples</div><div><div>This example shows how to display information about the parent and grand master of the PTP clock:</div><div>switch# show ptp parent Parent Clock: Parent Clock Identity: 0:18:ba:ff:ff:d8: e:16 Parent Port Number: 1546 Observed Parent Offset (log variance): N/A Observed Parent Clock Phase Change Rate: N/A Grandmaster Clock: Grandmaster Clock Identity: 0:18:ba:ff:ff:d8: e:16 Grandmaster Clock Quality: Class: 248 Accuracy: 254 Offset (log variance): 65535 Priority1: 255 Priority2: 255</div></div></div></div> <div>Cisco Nexus 7000 Series NX-OS System Management Command Reference (2013), at 607.</div>	Release	Modification	5.2(1)	This command was introduced.	<div><div>show ptp parent</div><div>The show ptp parent command displays information about the parent and grand master of the Precision Time Protocol (PTP) clock.</div><div>Platform Arad, FM6000 Command Mode Privileged EXEC</div><div><div>Command Syntax</div><div>show ptp parent</div></div><div><div>Examples</div><div><div>This command shows how to display information about the parent and master of the PTP clock.</div><div>switch# show ptp parent Parent Clock: Parent Clock Identity: 0x00:1c:73:ff:ff:00:72:40 Parent Port Number: 0 Parent IP Address: N/A Observed Parent Offset (log variance): N/A Observed Parent Clock Phase Change Rate: N/A Grandmaster Clock: Grandmaster Clock Identity: 0x00:1c:73:ff:ff:00:72:40 Grandmaster Clock Quality: Class: 248 Accuracy: 0x30 OffsetScaledLogVariance: 0xffff Priority1: 128 Priority2: 128 switch#</div></div></div></div> <div>Arista User Manual v. 4.14.3F – Rev. 2 (10/2/2014), at 352.</div> <div>See also Arista User Manual v. 4.12.3 (7/17/13), at 285; Arista User Manual, v. 4.11.1 (1/11/13), at 231.</div>	Dkt. 419-10 at PDF p. 411
Release	Modification					
5.2(1)	This command was introduced.					

Cisco's Documentation	Arista's Documentation	Supporting Evidence In The Record		
<div><div>show ptp time-property</div><div>To display the Precision Time Protocol (PTP) clock properties, use the show ptp time-property command.</div><div>show ptp time-property</div><div><div>Syntax Description</div><div>This command has no arguments or keywords.</div></div><div><div>Defaults</div><div>None</div></div><div><div>Command Modes</div><div>Any command mode</div></div><div><div>SupportedUserRoles</div><div>network-admin network-operator vdc-admin vdc-operator</div></div><div><div>Command History</div><table><thead><tr><th>Release</th><th>Modification</th></tr></thead><tbody><tr><td>5.2(1)</td><td>This command was introduced.</td></tr></tbody></table></div><div><div>Usage Guidelines</div><div>This command does not require a license.</div></div><div><div>Examples</div><div>This example shows how to display the PTP clock properties:</div><div>switch# show ptp time-property PTP CLOCK TIME PROPERTY: Current UTC Offset valid: 0 Current UTC Offset: 33 Leap59: 0 Leap61: 0 Time Traceable: 0 Frequency Traceable: 0 PTP Timescale: 0 Time Source: 0xA0 (internal Oscillator)</div></div></div> <div><div>Show PTP Clock Properties</div><div>To display the Precision Time Protocol (PTP) clock properties, use the show ptp time-property command.</div><div><ul style="list-style-type: none">The show ptp time-property command displays the Precision Time Protocol (PTP) clock properties.</div><div>switch# show ptp time-property Current UTC offset valid: False Current UTC offset: 0 Leap 59: False Leap 61: False Time Traceable: False Frequency Traceable: False PTP Timescale: False Time Source: 0x0 switch#</div><div>Arista User Manual v. 4.14.3F – Rev. 2 (10/2/2014), at 275-76.</div><div>See also Arista User Manual v. 4.12.3 (7/17/13), at 218.</div></div> <div>Dkt. 419-10 at PDF p. 412</div>	Release	Modification	5.2(1)	This command was introduced.
Release	Modification			
5.2(1)	This command was introduced.			

Cisco Nexus 7000 Series NX-OS System Management Command Reference (2013), at 611.

Cisco's Documentation	Arista's Documentation	Supporting Evidence In The Record				
<div><div>show ptp time-property</div><div>To display the Precision Time Protocol (PTP) clock properties, use the show ptp time-property command.</div><div>show ptp time-property</div><div><div>Syntax Description</div><div>This command has no arguments or keywords.</div></div><div><div>Defaults</div><div>None</div></div><div><div>Command Modes</div><div>Any command mode</div></div><div><div>SupportedUserRoles</div><div>network-admin network-operator vdc-admin vdc-operator</div></div><div><div>Command History</div><table><thead><tr><th>Release</th><th>Modification</th></tr></thead><tbody><tr><td>5.2(1)</td><td>This command was introduced.</td></tr></tbody></table></div><div><div>Usage Guidelines</div><div>This command does not require a license.</div></div><div><div>Examples</div><div>This example shows how to display the PTP clock properties:</div><div>switch# show ptp time-property PTP CLOCK TIME PROPERTY: Current UTC Offset valid: 0 Current UTC Offset: 33 Leap59: 0 Leap61: 0 Time Traceable: 0 Frequency Traceable: 0 PTP Timescale: 0 Time Source: 0xA0 (internal Oscillator)</div></div></div>	Release	Modification	5.2(1)	This command was introduced.	<div><div>show ptp time-property</div><div>The show ptp time-property command displays the Precision Time Protocol (PTP) clock properties.</div><div>Platform Arad, FM6000 Command Mode Privileged EXEC</div><div><div>Command Syntax</div><div>show ptp time-property</div></div><div><div>Examples</div><div><ul style="list-style-type: none">This command shows the PTP clock properties.<div>switch# show ptp time-property Current UTC offset valid: False Current UTC offset: 0 Leap 59: False Leap 61: False Time Traceable: False Frequency Traceable: False PTP Timescale: False Time Source: 0x0 switch#</div></div></div></div> <div>Arista User Manual v. 4.14.3F – Rev. 2 (10/2/2014), at 354.</div> <div>See also Arista User Manual v. 4.12.3 (7/17/13), at 287; Arista User Manual, v. 4.11.1 (1/11/13), at 233.</div>	Dkt. 419-10 at PDF p. 413
Release	Modification					
5.2(1)	This command was introduced.					

Cisco Nexus 7000 Series NX-OS System Management Command Reference (2013), at 611.

Cisco's Documentation	Arista's Documentation	Supporting Evidence In The Record
<p>Examples</p> <p>This example shows how to display the SNMP information:</p> <pre>switch(config)# show snmp sys contact: sys location: anyplace, Anywhere 0 SNMP packets input 0 Bad SNMP versions 0 Unknown community name 0 Illegal operation for community name supplied 0 Encoding errors 0 Number of requested variables 0 Number of altered variables 0 Get-request PDUs 0 Get-next PDUs 0 Set-request PDUs 0 SNMP packets output 0 Too big errors 0 No such name errors 0 Bad values errors 0 General errors</pre> <p>Cisco Nexus 7000 Series NX-OS System Management Command Reference (2013), at 634.</p>	<p>Example</p> <ul style="list-style-type: none"> This command configures <i>xyz-1234</i> as the chassis-ID string, then displays the result. <pre>switch(config)#snmp-server chassis-id xyz-1234 switch(config)#show snmp Chassis: xyz-1234 <---chassis ID 8 SNMP packets input 0 Bad SNMP version errors 0 Unknown community name 0 Illegal operation for community name supplied 0 Encoding errors 8 Number of requested variables 0 Number of altered variables 4 Get-request PDUs 4 Get-next PDUs 0 Set-request PDUs 21 SNMP packets output 0 Too big errors 0 No such name errors 0 Bad value errors 0 General errors 8 Response PDUs 0 Trap PDUs SNMP logging: enabled Logging to taccon.162 SNMP agent enabled switch(config)#</pre> <p>Arista User Manual v. 4.14.3F – Rev. 2 (10/2/2014), at 354.</p> <p>See also Arista User Manual v. 4.12.3 (7/17/13), at 1657-58; Arista User Manual, v. 4.11.1 (1/11/13), at 1344-45; Arista User Manual v. 4.10.3 (10/22/12), at 1111; Arista User Manual v. 4.9.3.2 (5/3/12), at 867; Arista User Manual v. 4.8.2 (11/18/11), at 678; Arista User Manual v. 4.7.3 (7/18/11), at 549.</p>	<p>Dkt. 419-10 at PDF p. 414</p>

Cisco's Documentation	Arista's Documentation	Supporting Evidence In The Record												
<p>show snmp engineID</p> <p>To display the Simple Network Management Protocol (SNMP) engine ID, use the <code>show snmp engineID</code> command.</p> <pre>show snmp engineID</pre> <p>Syntax Description This command has no arguments or keywords.</p> <p>Defaults None</p> <p>Command Modes Any command mode</p> <p>Supported User Roles network-admin network-operator vdc-admin vdc-operator</p> <table border="1"> <thead> <tr> <th>Command History</th><th>Release</th><th>Modification</th></tr> </thead> <tbody> <tr> <td></td><td>4.0(1)</td><td>This command was introduced.</td></tr> </tbody> </table> <p>Usage Guidelines This command does not require a license.</p> <p>Examples This example shows how to display the SNMP engine ID:</p> <pre>switch(config)# show snmp engineID Local SNMP engineID: [Hex] 80000009030005300A0B0C [Dec] 128:000:000:009:003:000:005:048:010:011:012</pre> <table border="1"> <thead> <tr> <th>Related Commands</th><th>Command</th><th>Description</th></tr> </thead> <tbody> <tr> <td></td><td>snmp-server user</td><td>Configures SNMP target notification users.</td></tr> </tbody> </table> <p>Cisco Nexus 7000 Series NX-OS System Management Command Reference (2013), at 639.</p>	Command History	Release	Modification		4.0(1)	This command was introduced.	Related Commands	Command	Description		snmp-server user	Configures SNMP target notification users.	<p>show snmp engineID</p> <p>The <code>show snmp engineID</code> command displays the identification of the local Simple Network Management Protocol (SNMP) engine and of all remote engines that are configured on the switch.</p> <p>Platform all Command Mode EXEC</p> <p>Command Syntax</p> <pre>show snmp engineID</pre> <p>Example</p> <ul style="list-style-type: none"> This command displays the ID of the local SNMP engine. <pre>switch>show snmp engineid Local SNMP EngineID: f5717f001c730436d700 switch></pre> <p>Arista User Manual v. 4.14.3F – Rev. 2 (10/2/2014), at 1978.</p> <p>See also Arista User Manual v. 4.12.3 (7/17/13), at 1668; Arista User Manual, v. 4.11.1 (1/11/13), at 1355; Arista User Manual v. 4.10.3 (10/22/12), at 1122; Arista User Manual v. 4.9.3.2 (5/3/12), at 878; Arista User Manual v. 4.8.2 (11/18/11), at 686; Arista User Manual v. 4.7.3 (7/18/11), at 542.</p>	<p>Dkt. 419-10 at PDF p. 415</p>
Command History	Release	Modification												
	4.0(1)	This command was introduced.												
Related Commands	Command	Description												
	snmp-server user	Configures SNMP target notification users.												

Cisco's Documentation	Arista's Documentation	Supporting Evidence In The Record
<p>Precision Time Protocol</p> <p>The Precision Time Protocol (PTP) is a time synchronization protocol for nodes distributed across a network. Its hardware timestamp feature provides greater accuracy than other time synchronization protocols such as Network Time Protocol (NTP). For more information about PTP, see Chapter 4, "Configuring PTP."</p> <p>Cisco Nexus 7000 Series NX-OS System Management Configuration Guide, Release 6.x (2013), at 1-3.</p>	<p>5.3.2 Precision Time Protocol (PTP)</p> <p>The Precision Time Protocol (PTP) can substantially enhance the accuracy of real-time clocks in networked devices by providing sub-microsecond clock synchronization. Inbound clock signals are organized into a master-slave hierarchy. PTP identifies the switch port that is connected to the device with the most precise clock. This clock is referred to as the master clock. All the other devices on the network synchronize their clocks with the master and are referred to as slaves.</p> <p>The master clock sends out a sync message every second. The slave clock sends a delay request message to the master clock noting the time it was sent in order to measure and eliminate packet delays. The master clock then replies with the time stamp the delay message was received. The slave clock then computes the master clock time compensated for delays and finalizes synchronization. Constantly exchanged timing messages ensure continued synchronization.</p> <p>Arista User Manual v. 4.14.3F – Rev. 2 (10/2/2014), at 270.</p> <p>See also Arista User Manual v. 4.12.3 (7/17/13), at 213; Arista User Manual, v. 4.11.1 (1/11/13), at 163.</p>	<p>Dkt. 419-10 at PDF p. 416</p>
<p>SNMP</p> <p>The Simple Network Management Protocol (SNMP) is an application-layer protocol that provides a message format for communication between SNMP managers and agents. SNMP provides a standardized framework and a common language used for the monitoring and management of devices in a network. For more information, see Chapter 11, "Configuring SNMP."</p> <p>Cisco Nexus 7000 Series NX-OS System Management Configuration Guide, Release 6.x (2013), at 1-5.</p>	<p>37.2 SNMP Conceptual Overview</p> <p>Simple Network Management Protocol (SNMP) is an application-layer protocol that provides a standardized framework and a common language to monitor and manage network devices.</p> <p>Arista User Manual v. 4.14.3F – Rev. 2 (10/2/2014), at 1961.</p> <p>See also Arista User Manual v. 4.12.3 (7/17/13), at 1651; Arista User Manual, v. 4.11.1 (1/11/13), at 1338; Arista User Manual v. 4.10.3 (10/22/12), at 1105; Arista User Manual v. 4.9.3.2 (5/3/12), at 861; Arista User Manual v. 4.8.2 (11/18/11), at 673; Arista User Manual v. 4.7.3 (7/18/11), at 529.</p>	<p>Dkt. 419-10 at PDF p. 416</p>

Cisco's Documentation	Arista's Documentation	Supporting Evidence In The Record				
<div>SNMP</div> <p>The Simple Network Management Protocol (SNMP) is an application-layer protocol that provides a message format for communication between SNMP managers and agents. SNMP provides a standardized framework and a common language used for the monitoring and management of devices in a network. For more information, see Chapter 11, "Configuring SNMP."</p> <p>Cisco Nexus 7000 Series NX-OS System Management Configuration Guide, Release 6.x (2013), at 1-5.</p>	<div>Chapter 37 SNMP</div> <p>SNMP is an application-layer protocol that provides a standardized framework and a common language to monitor and manage network devices.</p> <p>Arista User Manual v. 4.14.3F – Rev. 2 (10/2/2014), at 43.</p> <p>See also Arista User Manual v. 4.12.3 (7/17/13), at 37; Arista User Manual, v. 4.11.1 (1/11/13), at 31; Arista User Manual v. 4.10.3 (10/22/12), at 28; Arista User Manual v. 4.9.3.2 (5/3/12), at 24; Arista User Manual v. 4.8.2 (11/18/11), at 20; Arista User Manual v. 4.7.3 (7/18/11), at 18.</p>	Dkt. 419-10 at PDF p. 416				
<div>Configuring the NTP Source IP Address</div> <p>NTP sets the source IP address for all NTP packets based on the address of the interface through which the NTP packets are sent. You can configure NTP to use a specific source IP address.</p> <p>To configure the NTP source IP address, use the following command in global configuration mode:</p> <table><tr><th>Command</th><th>Purpose</th></tr><tr><td>[no] ntp source ip-address</td><td>Configures the source IP address for all NTP packets. The ip-address can be in IPv4 or IPv6 format.</td></tr></table> <p>Example: switch(config)# ntp source 192.0.2.1</p> <p>Cisco Nexus 7000 Series NX-OS System Management Configuration Guide, Release 6.x (2013), at 3-16.</p>	Command	Purpose	[no] ntp source ip-address	Configures the source IP address for all NTP packets. The ip-address can be in IPv4 or IPv6 format.	<div>Configure the Source IP</div> <p>To configure the source IP address for all PTP packets, use the ptp source ip command.</p> <ul style="list-style-type: none">The ptp source ip command configures the source IP address of 10.0.2.1 for all PTP packets. <pre>switch(config)# ptp source ip 10.0.2.1 switch(config)#</pre> <p>Arista User Manual v. 4.14.3F – Rev. 2 (10/2/2014), at 272.</p> <p>See also Arista User Manual v. 4.12.3 (7/17/13), at 215.</p>	Dkt. 419-10 at PDF p. 417
Command	Purpose					
[no] ntp source ip-address	Configures the source IP address for all NTP packets. The ip-address can be in IPv4 or IPv6 format.					

Cisco's Documentation	Arista's Documentation	Supporting Evidence In The Record
<p>Configuration Examples for NTP</p> <p>This example shows how to configure an NTP server and peer, enable NTP authentication, enable NTP logging, and then save the configuration in startup so that it is saved across reboots and restarts:</p> <pre> switch# config t Enter configuration commands, one per line. End with CNTL/Z. switch(config)# ntp server 192.0.2.105 key 42 switch(config)# ntp peer 2001:db8::4101 switch(config)# show ntp peers ----- Peer IP Address Serv/Peer ----- 2001:db8::4101 Peer (configured) 192.0.2.105 Server (configured) switch(config)# ntp authentication-key 42 md5 aNiceKey switch(config)# show ntp authentication-keys ----- Auth Key MD5 String ----- 42 aNicekey switch(config)# ntp trusted-key 42 switch(config)# show ntp trusted-keys Trusted Keys: 42 switch(config)# ntp authenticate switch(config)# show ntp authentication-status Authentication enabled. switch(config)# ntp logging switch(config)# show ntp logging NTP logging enabled. switch(config)# copy running-config startup-config [#####] 100% switch(config)# </pre> <p>Cisco Nexus 7000 Series NX-OS System Management Configuration Guide, Release 6.x (2013), at 3-25.</p>	<p>Example</p> <ul style="list-style-type: none"> These commands configure the switch to authenticate NTP packets using key 328 with the plaintext password "timeSync." <pre> switch(config)# ntp authentication-key 328 md5 timeSync switch(config)# ntp trusted key 328 switch(config)# ntp authenticate switch(config)# </pre> <p>Arista User Manual v. 4.14.3F – Rev. 2 (10/2/2014), at 270.</p>	<p>Dkt. 419-10 at PDF p. 417</p>

Cisco's Documentation	Arista's Documentation	Supporting Evidence In The Record
<p>Step 4 <code>[no] ptp domain number</code></p> <p>Example: <code>switch(config)# ptp domain 1</code></p> <p>Step 5 <code>[no] ptp priority1 value</code></p> <p>Example: <code>switch(config)# ptp priority1 10</code></p> <p>Step 6 <code>[no] ptp priority2 value</code></p> <p>Example: <code>switch(config)# ptp priority2 20</code></p> <p>Cisco Nexus 7000 Series NX-OS System Management Configuration Guide, Release 6.x (2013), at 4-6.</p>	<p>ptp domain</p> <p>The <code>ptp domain</code> command configures the domain number to use for the clock. PTP domains allow you to use multiple independent PTP clocking subdomains on a single network. To remove PTP settings, use the <code>no</code> form of this command.</p> <p>Platform Arad, FM6000 Command Mode Global Configuration</p> <p>Command Syntax</p> <p><code>ptp domain domain number</code> <code>no ptp domain</code> <code>default ptp domain</code></p> <p>Parameters</p> <ul style="list-style-type: none"> <code>domain_number</code> The domain number to use for the clock. Value ranges from 0 to 255. <p>Examples</p> <ul style="list-style-type: none"> This command shows how to configure domain 1 for use with a clock. <pre>switch(config)# ptp domain 1 switch(config)#</pre> This command removes the configured domain 1 for use with a clock. <pre>switch(config)# no ptp domain 1 switch(config)#</pre> <p>Arista User Manual v. 4.14.3F – Rev. 2 (10/2/2014), at 319.</p> <p>See also Arista User Manual v. 4.12.3 (7/17/13), at 257; Arista User Manual, v. 4.11.1 (1/11/13), at 204.</p>	<p>Dkt. 419-10 at PDF p. 418</p>

Cisco's Documentation	Arista's Documentation	Supporting Evidence In The Record
<p>Step 4 [no] ptp domain <i>number</i></p> <p>Example: switch(config)# ptp domain 1</p> <p>Step 5 [no] ptp priority1 <i>value</i></p> <p>Example: switch(config)# ptp priority1 10</p> <p>Step 6 [no] ptp priority2 <i>value</i></p> <p>Example: switch(config)# ptp priority2 20</p> <p>Cisco Nexus 7000 Series NX-OS System Management Configuration Guide, Release 6.x (2013), at 4-6.</p>	<p>ptp priority1</p> <p>The ptp priority1 command configures the priority1 value to use when advertising the clock. This value overrides the default criteria for best master clock selection. Lower values take precedence. The range is from 0 to 255. To remove PTP settings, use the no form of this command.</p> <p>Platform Arad, FM6000 Command Mode Global Configuration</p> <p>Command Syntax</p> <p>ptp priority1 <i>priority_rate</i> no ptp priority1 default ptp priority1</p> <p>Parameters</p> <ul style="list-style-type: none"> <i>priority_rate</i> The value to override the default criteria (clock quality, clock class, etc.) for best master clock selection. Lower values take precedence. Value ranges from 0 to 255. The default is 128. <p>Examples</p> <ul style="list-style-type: none"> This command configures the preference level for a clock; slave devices use the priority1 value when selecting a master clock. <pre>switch(config)# ptp priority1 120 switch(config)#</pre> <ul style="list-style-type: none"> This command removes the configured the preference level for a clock. <pre>switch(config)# no ptp priority1 switch(config)#</pre> <p>Arista User Manual v. 4.14.3F – Rev. 2 (10/2/2014), at 326.</p> <p>See also Arista User Manual v. 4.13.6F (4/14/2014), at 318; Arista User Manual v. 4.12.3 (7/17/13), at 262; Arista User Manual, v. 4.11.1 (1/11/13), at 208.</p>	<p>Dkt. 419-10 at PDF p. 419</p>

Cisco's Documentation	Arista's Documentation	Supporting Evidence In The Record
<p>Step 4 [no] ptp domain <i>number</i></p> <p>Example: switch(config)# ptp domain 1</p> <p>Step 5 [no] ptp priority1 <i>value</i></p> <p>Example: switch(config)# ptp priority1 10</p> <p>Step 6 [no] ptp priority2 <i>value</i></p> <p>Example: switch(config)# ptp priority2 20</p> <p>Cisco Nexus 7000 Series NX-OS System Management Configuration Guide, Release 6.x (2013), at 4-6.</p>	<p>ptp priority2</p> <p>The ptp priority2 command configures the priority2 value to use when advertising this clock. This value is used to decide between two devices that are otherwise equally matched in the default criteria. For example, you can use the priority2 value to give a specific switch priority over other identical switches. The range is from 0 to 255. To remove PTP settings, use the no form of this command.</p> <p>Platform Arad, FM6000 Command Mode Global Configuration</p> <p>Command Syntax</p> <pre>ptp priority2 priority_rate no ptp priority2 default ptp priority2</pre> <p>Parameters</p> <ul style="list-style-type: none"> <i>priority_rate</i> Sets a secondary preference level for a clock; slave devices use the priority2 value when selecting a master clock. Value ranges from 0 to 255. <p>Examples</p> <ul style="list-style-type: none"> This command sets a secondary preference level for a clock to 128. switch(config)# ptp priority2 128 switch(config)# This command removes the secondary preference level for a clock. switch(config)# no ptp priority2 switch(config)# <p>Arista User Manual v. 4.14.3F – Rev. 2 (10/2/2014), at 327.</p> <p>See also Arista User Manual v. 4.13.6F (4/14/2014), at 319; Arista User Manual v. 4.12.3 (7/17/13), at 263; Arista User Manual, v. 4.11.1 (1/11/13), at 209.</p>	<p>Dkt. 419-10 at PDF p. 420</p>

Cisco's Documentation	Arista's Documentation	Supporting Evidence In The Record
<p>BEFORE YOU BEGIN</p> <p>Make sure that you are in the correct VDC. To change the VDC, use the switchto vdc command.</p> <p>Make sure that you have globally enabled PTP on the device and configured the source IP address for PTP communication.</p> <p>Cisco Nexus 7000 Series NX-OS System Management Configuration Guide, Release 6.x (2013), at 4-7.</p>	<p>ptp delay-req interval</p> <p>The ptp delay-req interval command specifies the time recommended to the slave devices to send delay request messages. You must enable PTP on the switch first and configure the source IP address for PTP communication. To remove the minimum interval configuration for PTP delay-request messages, use the no form of this command.</p> <p>Arista User Manual v. 4.14.3F – Rev. 2 (10/2/2014), at 318.</p> <p>See also Arista User Manual v. 4.12.3 (7/17/13), at 256; Arista User Manual, v. 4.11.1 (1/11/13), at 202.</p>	<p>Dkt. 419-10 at PDF p. 420</p>

Cisco's Documentation	Arista's Documentation	Supporting Evidence In The Record
<p>Step 4 <code>[no] ptp announce (interval seconds timeout count)</code></p> <p>Example: <code>switch(config-if)# ptp announce interval 1</code></p> <p>(Optional) Configures the interval between PTP announce messages on an interface or the number of PTP intervals before a timeout occurs on an interface.</p> <p>The range for the PTP announcement interval is from 0 to 4 seconds, and the range for the interval timeout is from 2 to 10.</p> <p>Cisco Nexus 7000 Series NX-OS System Management Configuration Guide, Release 6.x (2013), at 4-8.</p>	<p>ptp announce interval</p> <p>The <code>ptp announce interval</code> command configures the interval between PTP announcement messages on or the number of PTP intervals before a timeout occurs. To disable this feature, use the <code>no</code> form of this command.</p> <p>Platform Arad, FM6000 Command Mode Interface-Ethernet Configuration Interface-Port Channel Configuration</p> <p>Command Syntax</p> <pre>ptp announce interval log_interval no ptp announce interval default ptp announce interval</pre> <p>Parameters</p> <ul style="list-style-type: none"> <code>log_interval</code> The number of log seconds between PTP announcement message (base 2 log (seconds)). Value ranges from 0 to 4; default value is 1. <p>Examples</p> <ul style="list-style-type: none"> This command shows how to configure the interval between PTP announce messages on an interface. <pre>switch(config)# interface ethernet 5 switch(config-if-Et5)# ptp announce interval 1 switch(config-if-Et5)#</pre> <ul style="list-style-type: none"> This command removes the configured interval between PTP announce messages on interface Ethernet 5. <pre>switch(config)# interface ethernet 5 switch(config-if-Et5)# no ptp announce interval switch(config-if-Et5)#</pre> <p>Arista User Manual v. 4.14.3F – Rev. 2 (10/2/2014), at 315.</p> <p>See also Arista User Manual v. 4.12.3 (7/17/13), at 252; Arista User Manual, v. 4.11.1 (1/11/13), at 199.</p>	<p>Dkt. 419-10 at PDF p. 421</p>

Cisco's Documentation	Arista's Documentation	Supporting Evidence In The Record
<p>Step 5 [no] ptp delay-request minimum interval <i>seconds</i></p> <p>Example: switch(config-if)# ptp delay-request minimum interval 3</p> <p>(Optional) Configures the minimum interval allowed between PTP delay-request messages when the port is in the master state. The range is from -1 to 6 seconds.</p> <p>Cisco Nexus 7000 Series NX-OS System Management Configuration Guide, Release 6.x (2013), at 4-8.</p>	<p>ptp delay-request interval</p> <p>The ptp delay-request interval command specifies the time recommended to the slave devices to send delay request messages. You must enable PTP on the switch first and configure the source IP address for PTP communication. To remove the minimum interval configuration for PTP delay-request messages, use the no form of this command.</p> <p>Platform Arad, FM6000 Command Mode Interface-Ethernet Configuration Interface-Port Channel Configuration</p> <p>Command Syntax</p> <pre>ptp delay-request interval log_interval no ptp delay-request interval default ptp delay-request interval</pre> <p>Parameters</p> <ul style="list-style-type: none"> <i>log_interval</i> The range is -1 second to 8 seconds. The default is 5 log(seconds). <p>Examples</p> <ul style="list-style-type: none"> This command shows how to configure the minimum interval allowed between PTP delay-request messages. <pre>switch(config)# interface ethernet 5 switch(config-if-Et5)# ptp delay-request interval 3 switch(config-if-Et5)#</pre> This command removes the configured minimum interval allowed between PTP delay-request messages. <pre>switch(config)# interface ethernet 5 switch(config-if-Et5)# no ptp delay-request interval switch(config-if-Et5)#</pre> <p>Arista User Manual v. 4.14.3F – Rev. 2 (10/2/2014), at 318.</p> <p>See also Arista User Manual v. 4.12.3 (7/17/13), at 256; Arista User Manual, v. 4.11.1 (1/11/13), at 202.</p>	<p>Dkt. 419-10 at PDF p. 422</p>

Cisco's Documentation	Arista's Documentation	Supporting Evidence In The Record																
<div>Verifying the PTP Configuration</div> <div>To display the PTP configuration, perform one of the following tasks:</div> <table><thead><tr><th>Command</th><th>Purpose</th></tr></thead><tbody><tr><td>show ptp brief</td><td>Displays the PTP status.</td></tr><tr><td>show ptp clock</td><td>Displays the properties of the local clock.</td></tr><tr><td>show ptp clock foreign-masters record [interface interface slot/port]</td><td>Displays the state of foreign masters known to the PTP process. For each foreign master, the output displays the clock identity, basic clock properties, and whether the clock is being used as a grandmaster.</td></tr><tr><td>show ptp corrections</td><td>Displays the last few PTP corrections.</td></tr><tr><td>show ptp parent</td><td>Displays the properties of the PTP parent.</td></tr><tr><td>show ptp port interface interface slot/port</td><td>Displays the status of the PTP port.</td></tr><tr><td>show ptp time-property</td><td>Displays the properties of the PTP clock.</td></tr></tbody></table> <div>Cisco Nexus 7000 Series NX-OS System Management Configuration Guide, Release 6.x (2013), at 4-9.</div>	Command	Purpose	show ptp brief	Displays the PTP status.	show ptp clock	Displays the properties of the local clock.	show ptp clock foreign-masters record [interface interface slot/port]	Displays the state of foreign masters known to the PTP process. For each foreign master, the output displays the clock identity, basic clock properties, and whether the clock is being used as a grandmaster.	show ptp corrections	Displays the last few PTP corrections.	show ptp parent	Displays the properties of the PTP parent.	show ptp port interface interface slot/port	Displays the status of the PTP port.	show ptp time-property	Displays the properties of the PTP clock.	<div>show ptp foreign-master-record</div> <div>The show ptp foreign-master-record command displays information about the state of foreign masters known to the Precision Time Protocol (PTP) process.</div> <div>PlatformArad, FM6000</div> <div>Command ModeEXEC</div> <div>Command Syntax</div> <div>show ptp foreign-master-record</div> <div>Examples</div> <div><ul style="list-style-type: none">This command shows how to display information about the state of foreign masters known to the PTP process.</div> <div>switch# show ptp clocks foreign-masters-record</div> <div>No Foreign Master Records</div> <div>switch#</div> <div>Arista User Manual v. 4.14.3F – Rev. 2 (10/2/2014), at 349.</div> <div>See also Arista User Manual v. 4.12.3 (7/17/13), at 282; Arista User Manual, v. 4.11.1 (1/11/13), at 228.</div>	<div>Dkt. 419-10 at PDF p. 423</div>
Command	Purpose																	
show ptp brief	Displays the PTP status.																	
show ptp clock	Displays the properties of the local clock.																	
show ptp clock foreign-masters record [interface interface slot/port]	Displays the state of foreign masters known to the PTP process. For each foreign master, the output displays the clock identity, basic clock properties, and whether the clock is being used as a grandmaster.																	
show ptp corrections	Displays the last few PTP corrections.																	
show ptp parent	Displays the properties of the PTP parent.																	
show ptp port interface interface slot/port	Displays the status of the PTP port.																	
show ptp time-property	Displays the properties of the PTP clock.																	

Cisco's Documentation	Arista's Documentation	Supporting Evidence In The Record
<p>SNMP Functional Overview</p> <p>The SNMP framework consists of three parts:</p> <ul style="list-style-type: none"> • An SNMP manager—The system used to control and monitor the activities of network devices using SNMP. • An SNMP agent—The software component within the managed device that maintains the data for the device and reports these data, as needed, to managing systems. Cisco NX-OS supports the agent and MIB. To enable the SNMP agent, you must define the relationship between the manager and the agent. • A managed information base (MIB)—The collection of managed objects on the SNMP agent. SNMP is defined in RFCs 3411 to 3418. <p>Cisco NX-OS supports SNMPv1, SNMPv2c, and SNMPv3. Both SNMPv1 and SNMPv2c use a community-based form of security.</p> <p>Cisco NX-OS supports SNMP over IPv6.</p> <p>Cisco Nexus 7000 Series NX-OS System Management Configuration Guide, Release 6.x (2013), at 11-2.</p>	<p>37.2.3 SNMP Versions</p> <p>Arista switches support the following SNMP versions:</p> <ul style="list-style-type: none"> • SNMPv1: The Simple Network Management Protocol, defined in RFC 1157. Security is based on community strings. • SNMPv2c: Community-string based Administrative Framework for SNMPv2, defined in RFC 1901 RFC 1905, and RFC 1906. SNMPv2c uses the community-based security model of SNMPv1. • SNMPv3: Version 3 is an interoperable standards-based protocol defined in RFCs 2273 to 2275. SNMPv3 provides secure access to devices by authenticating and encrypting packets. <p>The security features provided in SNMPv3 are as follows:</p> <ul style="list-style-type: none"> — <i>Message integrity:</i> Ensures packets are not tampered with in transit. — <i>Authentication:</i> Determines the message is received from a valid source. — <i>Encryption:</i> Scrambling packet contents to prevent an unauthorized source from learning it. <p>Both SNMPv1 and SNMPv2c use a community-based form of security. The community of managers able to access the agent MIB is controlled by a password.</p> <p>Arista User Manual v. 4.14.3F – Rev. 2 (10/2/2014), at 349.</p> <p><i>See also</i> Arista User Manual v. 4.13.6F (4/14/2014), at 1891; Arista User Manual v. 4.12.3 (7/17/13), at 1654; Arista User Manual, v. 4.11.1 (1/11/13), at 1341; Arista User Manual v. 4.10.3 (10/22/12), at 1107; Arista User Manual v. 4.9.3.2 (5/3/12), at 863; Arista User Manual v. 4.8.2 (11/18/11), at 675; Arista User Manual v. 4.7.3 (7/18/11), at 531.</p>	<p>Dkt. 419-10 at PDF p. 424</p>